


## 06-08 Ford F-150 Diamond Back Bumper Installation Instructions. With Sensors Part #100-10-6012, With Sensors and lights Part #100-10-6013



**Step 1:** Remove OEM factory bumper.

**Step 2:** Align Frontier bumper to end of frame. Install bolts from the outside of Frontier Back Bumper through the bracket and the frame using 3/8" X 1-1/2" bolts, nuts, and washers.

**Step 3:** If an impact is used, drive the bolt and hold the nut. To verify that the bolts are tight, check with a wrench by hand.

**Step 4:** Attach license plate with 1/4" bolts, nuts, and washers.

**Step 5: Sensor Ready models:** If grommets are not already inserted in Frontier bumper then insert grommets into Frontier bumper. Remove sensors from OEM factory bumper and insert them into grommets.

**Note:** Periodically check bolts to ensure that bolts remain tight. Also, before using with a trailer, check bolts to ensure that bolts are tight.

### Bolt Bag Contents

Quantity	Description
6	3/8" X 1 1/2" Bolts
6	3/8" Lock Nuts
12	3/8" Flat Washers
4	1/4" X 1" bolts
4	1/4" hex nuts
8	1/4" flat washers
4	1/4" lock washers
4	Grommets (Sensor Ready bumpers only)
48	Total Pieces

**WARNING: Truck must  
come with factory hitch in  
order to work**